


Rev. A		Control Number XXXXXXXXXXXX
Effective Date 2/23/2010	Instructions for Accessing the Console Components on some Horizon Treadmills	Page 1/1
Revised Date 2/23/2010	Approved by Bill Baier	Prepared by Kevin Oeltjenbruns

PURPOSE

Explains how to access the console components on some Horizon Treadmills.

PROCEDURE

- 1) The console faceplate is held to the console frame with 4-6 screws (depending on the model). Locate the screws that go into the console faceplate through the back of the console and remove them. The picture below shows an example with 5 screws.



- 2) Once the screws are removed, the console faceplate can be leaned away from the console frame.



- 3) The console components can now be accessed on the back of the console faceplate.

